## Important Application Note for Raspberry Pi 4 or higher.

The SPI clock speed in the Raspberry Pi is calculated from the CPU clock.

In the example application this value is set to: BCM2835\_SPI\_CLOCK\_DIVIDER\_16, that is correct for Raspberry Pi up to version 3.

From Raspberry 4 due to a higher CPU speed this value is to change to: **BCM2835\_SPI\_CLOCK\_DIVIDER\_32**.

So if You use a Raspberry Pi 4 or higher in the example application change the value BCM2835\_SPI\_CLOCK\_DIVIDER\_16 to BCM2835\_SPI\_CLOCK\_DIVIDER\_32.